

## EGO GLÄTTMITTEL ORIGINAL

is a fluid, colourless, eudermic smoothing agent for all kinds of substrates

### APPLICATION AREAS

EGO GLÄTTMITTEL is suitable for silicone, polyurethane, SMP polymer and acrylic sealants.

### APPLICATION NOTES

- ① Apply sparingly onto the joint surface and remove spilled smoothing agent immediately – do not allow the product to dry.
- ② In case of sensitive substrates (wood, rough or absorbant substrates etc.), mask the adjoining areas with adhesive tape
- \* Notes:
  - For natural stone please use EGO STEINGLÄTTMITTEL for Stone Silicone.

### SPECIFICATIONS

Properties	Result
Dosage EGO GLÄTTMITTEL ORIGINAL	Can be diluted with clear water, mixing ratio 1:4 to max 1:5r
Dosage EGO GLÄTTMITTEL KONZENTRAT	Can be diluted with clear water, mixing ratio 1:100 (use three caps of concentrate for 1L water)
Compatibility	Free from tensides and substances that may discolour the sealant
pH Value	approx. 7

### AVAILABILITY AND STORAGE

Colour	Colourless
Packaging	<ul style="list-style-type: none"> <li>▪ 500 ml PE-can</li> <li>▪ 5 L PE-canister</li> <li>▪ 200 L drum</li> </ul>
Storage	Store in original packaging in a cool, dry place: <ul style="list-style-type: none"> <li>▪ 12 months</li> </ul>

### SAFETY INFORMATION

Meets Requirements of	REACH Regulation (EC) No. 1907/2006 and No. 1272/2008 CLP
Labelling	See EC safety data sheet
Safety Guidelines	See EC safety data sheet
Disposal	See EC safety data sheet

For warnings see EC safety data sheet. The above information is the result of thorough research; previous information is hereby invalidated. Check for yourself whether the product is suitable for your purposes. Our possible liability is limited to the value of our product as such. We cannot accept any liability for indirect damage, in particular for the use or unusability of the product. No one is authorized to make recommendations or assurances on our behalf that go beyond the content of our information sheets.